

GO! Radio Programming Guide

Please first download, install, and open the GO! Software (available [here](#))

Step 1: With the radio off, Insert USB cable into computer and 2 pin connector into GO!

Step 2: Turn on the radio.

Step 3: Within the software, choose a COM port (USB port) by selecting an option under **Port** from the top menu bar.

COM options for each computer vary; trial and error may be needed for Step 4.


Step 4: Click the **Read** button on the top menu to get current frequencies on radio and verify COM port.

Step 5: To change frequencies, select **Analog Channel** or **Digital Channel** in the menu on the lower left hand side of the screen.

Step 6: Click an individual channel and its settings tab will open up in your workspace.

Step 7: Change to desired TX (transmit) and RX (receive) options on all 16 channels

Step 8: Click on the **Write** button at the top of the screen, and then **Yes** on the following popup



You should see a progress bar fill to completion, and then your radio is ready to go!

STEP 9: Save your file for future use by selecting **File > Save**