

## Klein Pocket Radio Programming Guide

First, please download, install, and open the software (available [here](#)) on a Windows computer. It will be named Klein RadioSoft in your program list.

Step 1: Power off the Pocket radio by holding the power button (on the back of the radio) for 5 seconds until beeping tone.

Step 2: Insert USB cable into computer and connect your radio.

Step 3: Press and hold the radio's power button until the front LED ring goes dark (it will be green initially).

Step 4: From the top menu bar, select **Setting > Set Com** and choose the port the radio is connected.

*Trial and error may be needed on Step 5 if you have multiple COM options*

Step 5: Confirm proper radio connection by selecting **Program > Read from Radio**.

*Failure at this point means the radio wasn't connected properly or is connected to a different COM port.*

Step 6: You should now see a table with frequency information. You can manipulate this data to program custom frequencies and codes.

Step 7: Write your frequencies to the radio by selecting **Program > Write to Radio**.

Step 8: Save your file for future use by selecting **File > Save As**. You can Open this file and write it to radios in the future.