

# POCKET<sup>®</sup>

2-WAY RADIO




blackbox<sup>®</sup>

2-way radios

# Basic Information

## Including

Radio Body x1, Battery x1, Adaptor x1, Charging Cable x1, Belt Clip x1, Hand Strap x1, User Manual x1



## Basic Parameter


Dimension: 123x52x21.5mm

Weight: 80g

Storage Channel: 16CH

Operating Voltage: 3.3-4.2V DC


Operating Temperature: -20°C~-50°C



- |                   |                     |
|-------------------|---------------------|
| ① Microphone      | ⑧ Channel -         |
| ② PTT Key         | ⑨ Volume Key        |
| ③ Breathing Light | ⑩ MIC Jack          |
| ④ Speaker         | ⑪ Earphone Jack     |
| ⑤ Antenna         | ⑫ USB Charging Port |
| ⑥ Side PTT Key    | ⑬ Power On/Off      |
| ⑦ Channel +       | ⑭ Battery           |

## I Power On/Off


Long press "Power On/Off" Key for 2 seconds to turn on/off the radio.



## II Channel Selection


Short press "Channel +" to increase the channel number.

Short press "Channel - " to decrease the channel number.




### III Push To Talk

Press "PTT Key / Side PTT Key" to transmit, release to exit.




### IV Monitor Function

Press for 2 seconds to monitor the local airwaves.




## V Current Channel Broadcast

Long press "Channel + " for 1.5S to know the current channel.



## VI Volume Adjust

Toggle "Volume +" to increase the volume, toggle "Volume - " to decrease the volume. You will hear a beep sound when the volume is maximum or minimum.



## VII Breathing Light

After being in Standby mode for a bit, the “breathing” light will activate. Every 5 seconds it glows for a bit.

## VIII Scan Function

Scan function is activate in No. 16 channel, stop to scan after exiting No.16 channel.

*Hassle Free*

**180 DAY WARRANTY!**


For warranty information  
contact your dealer or email  
[support@kleinelectronics.com](mailto:support@kleinelectronics.com)

**POCKET**<sup>®</sup>  
2-WAY RADIO

## Care and Cleaning

To guarantee optimal performance as well as a long service life of the product, please follow the tips below.

- Do not puncture or scratch the product with hard objects.
- Do not place the product in corrosive agents, solutions or water.
- Do not handle the radio by its antenna or external microphone directly.
- When not in use, keep the accessory jacks covered with the protective caps.

 Power off the product, and remove the battery before cleaning.

- Clean up the dust and fine particles on the product parts with a clean and dry lint-free cloth or a brush regularly.
- Use a non-woven fabric with neutral cleanser to clean the keys, control knobs, and shell after long-time use.  
Do not use chemical preparations such as stain removers, alcohol, sprays or oil preparations.

**blackbox**<sup>®</sup>  
2-way radios